


Type RVI - Tableau des dimensions disponibles en standard

Diamètre de vis (D)	Nombre de filets (N)	Pas (P)															
		1	2	3	4	5	6	7	8	9	10	12	14	15	16		
10,5	3		x														
12	3	x	x														
13,5	3	x	x														
15	3	x	x	x													
18	3	x	x	x													
21	3		x	x	x												
24	3		x	x	x	x											
27	3		x	x	x	x											
28	4		x	x	x	x	x										
30	3		x	x	x	x	x										
36	4		x	x	x	x	x	x									
39	3			x	x	x	x	x	x								
44	4			x	x	x	x	x	x	x							
48	3			x	x	x	x	x	x	x	x						
51	3			x	x	x	x	x	x	x	x						
56	4				x	x	x	x	x	x	x	x					
60	4				x	x	x	x	x	x	x	x	x				
64	4				x	x	x	x	x	x	x	x	x	x			
70	5						x		x		x	x	x	x			
75	5						x		x		x	x	x	x			
80	4						x		x		x	x	x		x		

Type RVI



RVI 8 x 0.5



RVI 39 x 6